

Admins Quick Start Guide

Fleet Management Dashboard



Access to X-Rite Link



Access X-Rite Link in 3-steps:

- 1. A system administrator will grant you access
- 2. You will receive a welcome email from *no-reply* @xrite.com
- 3. Login using your existing My X-Rite login credentials or with the temporary password provided in the welcome email

link.xrite.com





Welcome to X-Rite Link.

Centralized fleet management and color insights from the experts at X-Rite Pantone


To access X-Rite Link, sign in to link.xrite.com

You can use your existing my.xrite.com account information to sign in If you have forgotten your password, you can request a password reset at account.xrite.com

Thank you, The X-Rite Team




Devices - Fleet View





Clear visibility of your instrument fleet with at-a-glance location and status tracking






Device Details - Overview



Detailed device overview to stay informed about your instrument







Device Details - NetProfiler



Device level NetProfiler details to monitor performance




NetProfiler Statistics - Fleet Level






Fleet level NetProfiler tracking to monitor compliance and inter-instrument agreement




Service - Records and Statistics








View active service cases in real time and track past cases




Adding New Locations





Devices and users are assigned to locations for easy sorting and permission setting



Create a new Toplevel location

Add a street address to see the location on the interactive map



Adding New Admins & Users





Welcome email will be sent to new users with access details

