



InkFormulation/ColorQuality - Online Client Installation

Client driver

To connect the devices eXact, Ci4200, Ci4200UV, Ci52, Ci62, Ci64, Ci64UV, Ci7600 and Ci7800 with the online version of InkFormulation 6 and ColorQuality 6, an additional driver has to be installed **on the client computer**. The driver is available for download on www.xrite.com. Depending on the SpectroServer version of the online system, the following driver version is requested:

SpectroServer	Client driver	Supported measurement devices
3.1	Terminal Server: eXact Online Client 1.0	eXact
3.2	Terminal Server: InkFormulation/ColorQuality Client 1.0	eXact, Ci4200, Ci4200UV
3.3	Terminal Server: InkFormulation/ColorQuality Client 1.1 Citrix: InkFormulation/ColorQuality Citrix Client 1.1 or Terminal Server: InkFormulation/ColorQuality Client 1.2 Citrix: InkFormulation/ColorQuality Citrix Client 1.2	eXact, Ci4200, Ci4200UV, Ci62, Ci64, Ci64UV
3.4	Terminal Server: InkFormulation/ColorQuality Client 1.2 Citrix: InkFormulation/ColorQuality Citrix Client 1.2	eXact, Ci4200, Ci4200UV, Ci52, Ci62, Ci64, Ci64UV
3.41	Terminal Server: InkFormulation/ColorQuality Client 1.41 Citrix: InkFormulation/ColorQuality Citrix Client 1.31	eXact, Ci4200, Ci4200UV, Ci52, Ci62, Ci64, Ci64UV, Ci7600, Ci7800

Instrument driver

In addition to the client driver, the instrument driver located on the instrument installation CD needs to be installed on the client computer.

64-Bit Client computers

64-Bit client computers no longer require a batch script for client driver version 1.41 (Citrix: 1.31).