

IntelliTrax v1.5 Feature Matrix



	Feature	Detail	ITX D	ITX S	ICC
1	G7 Process Control	Support for G7 Process Control	x	o	o
2	Measure P2P Target for G7	Measure P2P target and output file to other applications (example: IDEALink Curve Software)	x	x	o
3	G7 Reports	Report to show targets against G7 Job	x	o	o
4	ISO Support	Support for ISO targets	o	o	o
5	ISO Report	Report to show targets against ISO Job	o	o	o
6	Best Match	Best Match Function - Indicates if a close match to your reference color can be achieved by adjusting the ink thickness on press Provides density information for the reference and the sample and recommendations on how to adjust the ink to get the best match Apply the closest ink unit based on calculations of previous measurements to show the best DE.	x	o	o
7	Sheet Trend Graphs	Ability to run trend reports on sheets within a job. Shows results against tolerances and high/low values per sheet.	o	o	o
8	Support Custom Color Chart measurement	Allow user to measure a custom color chart and generate a measurement result in text format	x	x	o
9	Import Colorbar	Import a color bar data (PDF) to Color bar Library	o	o	o
10	Memo Function	Ability to add memo to sheet.	o	o	o
11	Delete, Rename Project and Job Name	Jobs and Projects can now be renamed or deleted from Job Info.	o	o	o
12	Sheet report from PressTool	User can run a sheet report from the PressTool	o	o	o
13	CxF2.0	Ability to import and export CxF2.0 Files (note: support for CxF1.0 is for import only)	o	o	o
14	Quick Target Changes	Ability to open the targets dialog and modify the target without opening the modify dialog box	o	o	o
15	Shift function in color bar view	If color bar recognition was shifted, in the view screen you can adjust the position manually.	o	o	o
16	New entry solution to library for 530	Enter a spot color measured by 530 to the library.	o	o	o
17	Press Key Definition	Ability to adjust 1st and last key zone to allow for varying size keys	o	o	o
18	Multi-page profile creation	Allows to measure a profiling target with multiple sides.	x	x	o
19	Enhancements to Gray balance Graphs	Modified the display of gray balance. PressTool graphs shows the mix of Cyan, Magenta and Yellow	o	o	o
20	8 Graph indication	8 graphs can be indicated in one screen. This can be set in the Local Machine Configuration Tool. The default is 6 graphs.	o	o	o
21	Auto Archive Improved Functionality	During PressTool startup, the software checks to see if an auto archive has been conducted in the last 30 days. If not one will be performed in the background	o	o	o
22	Usability Enhancements in Local Machine Configuration Tool (LMCT)	Add to the Local Machine Configuration Tool: 1) Ability to set the colorbar placement (Left, Center or Right Aligned) 2) Ability to turn on and off log files (default OFF) 3) Add a button to delete log files older than 1 month	o	o	o
23	XY Position	If the user saves the XY position of a color bar and then makes other job setup changes in the PressTool, the XY setting will be saved.(this does not pertain to the reloading of a job, only to job setup changes.)	o	o	o
24	Add Russian Language	Add translations in Russian	o	o	o
26	Color bar flop	After a color bar has been flopped in the Press Tool Color Bar Dialog, the user is now able to change ink unit locations in the color bar	o	o	o
27	Dot gain calculation	Dot gain calculation will be made with the measured paper value	o	o	o
28	New Diagnostics Tool	Diagnostics Tool in ToolCrib. Used by the director of applications to run tests on the system functions. Results can be sent to X-Rite for evaluation.	o	o	o
29	Vista	v1.5 is compatible with Vista. The IntelliTrax install will disable UAC feature of windows Vista Operating system	o	o	o
30	Service Packs	Add Service Pack 1 and Service Pack 2 for pattern recognition improvements and database functionality improvements	o	o	o