Instructions: Copy/Paste Meta Data

- 1. An option introduced in version 3.6 allows the ability to add meta data by pasting the information from a spreadsheet.
 - a. Copy the meta data information from your spreadsheet
 - b. Click the Paste From Clipboard Button

0.0	ColorCert®	
[Job Setup Wizard]		ECH
	Your ColorCert [®] Job Please enter required Job Information	
Job Name:		
TargetC#/Promo ID		•
Customer:		•
SPG		•
Brand:		•
Packaging Format		•
DPCI - TCIN		•
Order Code		•
Artwork Final Release Date		
Supply As:	Roll Pallet Sam	nple
	Paste From Clipboard	
xrite €	Back	Cancel Continue
Markine .	Back	Cancer



Instructions: Copy/Paste Meta Data

As soon as you click the button, the meta data fields will populate with the appropriate information.

c. Click the *Continue* button to proceed

O O	ColorCert [®]			
[Job Setup Wizard]		A. W.Y.	<u>S</u> C	
	Your ColorCert® Please enter required Job Inform			
Job Name:	PL1801Y01UPC-NS10001		•	
TargetC#/Promo ID	C-000699-01-003		•	
Customer:	NOBLAND INTERNATIONAL INC	>	•	
SPG	PBRD_HAT_0323		•	
Brand:	ETA_HT		•	
Packaging Format	Prologue:Packaging (Hang Tag)		•	
DPCI - TCIN	common packaging		•	
Order Code	PL18_01Y01		*	
Artwork Final Release Date	553426-PLUS%%			
Supply As:	Roll Pallet	Sample		
	Paste From Clipboard			
x•rite	Back	11	Cancel	Continue

