



Ci61+RTL

Portable Spectrophotometer



Precise Color Measurement On The Go

Give clients a superior experience and quickly generate paint color matches for even the most challenging inspirational items.

Fast, accurate measurement of walls, carpeting, paint chips and other inspirational items saves time and reduces waste in the paint matching process. Both contractors and paint retailers will appreciate the portable convenience and ease of use of the Ci61+RTL portable spectrophotometer – on the job site, in store or anywhere inspiration needs to be captured.

Designed With Busy Professionals In Mind

The Ci61+RTL offers many capabilities that contractors and paint retailers will wonder how they ever lived without:

- Easy menu navigation with large color display and touch controls. Screen lock prevents accidental measurements and loss of data.
- Flip-back measurement shoe and remote instrument trigger for easy access to difficult-to-measure surfaces.
- Correlated 60° gloss value delivers sheen identification and paint matching recommendations via remote connection.
- A rugged, ergonomic design that is easy to hold. Its carrying case offers protection and makes the Ci61+RTL easy to take anywhere.
- Powered by standard Li-ion batteries; optional external dual bay battery charger and spare batteries available.

Ci61+RTL Portable Spectrophotometer



Rugged and portable



Precise color measurement on the go



Sheen identification with 60° gloss value

Make Ci61+RTL a Complete Solution

ColorDesigner PLUS

X-Rite's ColorDesigner PLUS color matching software expedites and refines the paint selection process to eliminate wasted effort and needless formulation errors. It can connect to a paint dispenser system for fast delivery of paint color formulations, mix the customer's color in the paint product they want, and look up colors across paint lines (optional), turning any paint department into a color design center.

WS60 Series

Our W Series product bundles offer various combinations of color matching hardware and formulation software to meet the needs of retail paint operations of all sizes. The WS60 Series is a customizable hardware and software bundle to help paint counter associates match customer samples on the go.

Specifications

	Ci61+RTL
Short Term Repeatability - White	.10 ΔE^*ab on white ceramic
Measurement Geometry	d/8°
Inter-Instrument Agreement	Avg. 0.30 E^*ab based on avg. of 12 BCRA Series II tiles
Light Source	Gas-filled tungsten lamp
Measurement Spot	8mm measurement area / 14mm target window
Spectral Range	400 – 700nm
Dimensions	4.3"H x 3.6"W x 8.4"L

Full list of specifications available at www.xrite.com/ci61rtl

Service Support & Warranty

X-Rite's color analysis and measurement solutions are engineered and manufactured to the most rigorous quality standards. These standards are backed by comprehensive global service, superior phone and web support, and preventative maintenance options to optimize your long-term investment. We have developed service support and warranty plans that are unique to your organization's specific products and needs.

Learn more by reviewing our service offerings on our website at: www.xrite.com/page/service-warranty.

Still unsure of what you need? Contact us directly at: servicesupport@xrite.com



X-Rite is either a registered trademark or trademark of X-Rite, Incorporated in the United States and/or other countries. PANTONE®, PantoneLIVE and other Pantone trademarks are the property of Pantone LLC. All other trademarks or registered trademarks are the property of their respective owners. © X-Rite, Inc. 2020. All rights reserved. L3-267-EN (01/20)

xrite.com/ci61rtl