



Auto Search & Correct

Web Software

Search and Automatically Correct Paint Recipes

Auto Search & Correct Web software builds on the success of X-Rite's desktop application, enabling refinish paint companies to quickly and easily obtain automotive paint formulas for solid and effect colors, either from existing color libraries or by applying automatic paint formulas for solid and effect colors. The new web platform runs in a secure environment and enables access to synchronized color data anytime, anywhere through PC, tablet, or mobile device to simplify the paint correction process.

Finding the best effect paint color recipe can be a challenge. Online look up systems from VIN and Color Codes often yield poor color matches or no recipe found. X-Rite's Auto Search & Correct software provides refinish paint companies the ability to search and automatically correct paint recipes for measured vehicles in need of repair. This software provides users the most advanced search and correction algorithms to ensure best match quality.

Modern Web-Based Architecture

- Fast and secure access through a desktop, tablet, or mobile device browser with no installation required.
- Simplify the process for refinish paint companies to update, distribute, and differentiate their brand through custom branded websites to enable the best service level and functionality to their customers.
- Immediate data synchronization with new recipes, stored securely in the AWS cloud and protected by Amazon Shield Advanced.

Fast, Easy and Precise Automotive Paint Matching

- Leverage advanced formulation algorithms and search metrics to increase consistency across multiple locations for faster turn time on automotive painting jobs.
- Utilize searching metrics based on the spectral footprint to provide more accurate color searches.
- Correct existing library recipes to achieve a superior color match and an advanced effect formulation engine.
- Obtain acceptable color matches in fewer steps with correction capabilities for all types of toners, including effects.

Auto Search & Correct Web Software

Make Auto Search & Correct a Complete Solution

Auto Search & Correct software supports the X-Rite family of multi-angle spectrophotometers, including the following instruments:

- MA-3 and MA-5: Entry-level multi-angle spectrophotometers that allow automotive refinishers to quickly and easily match paint for precise digital formula matches.
- MA-T5: A multi-angle spectrophotometer that offers color imaging to effectively measure color, sparkle, and coarseness.



System Requirements

Auto SC Web Application

 Web browser supported: Google Chrome running version 80.0.x.x or Microsoft Edge 81.0.416.x, or newer (additional browsers maybe functional but unconfirmed)

Internet Connection: Minimum 2mbs

Bridge Application (optional for sending jobs via USB to PC and configuring devices)

Operating System: Windows 10

CPU: Core i3

RAM: 8 GB

Free HD Space: 5GB

Service Support & Warranty

Drawing on our extensive experience in the world of color, X-Rite Pantone offers the right level of services, onsite and online, to support and nurture your business. Call on us for standard color services and training, or work with us to tailor training and services to your specific needs. We help you get color right the first time, every time. For more information about extended support options, visit www.xrite.com/extended-warranties-services.

