



i1 Paint Spectrophotometer



Paint Color Matches on Common Samples

i1 Paint is a cost-effective and easy-to-use handheld spectrophotometer to help retail paint associates color match customer samples. It provides a quality paint match on common samples, including fan decks, color cards, and painted items.

i1 Paint integrates with ColorDesigner PLUS paint software to quickly formulate and store custom paint recipes. Compared to visual color matching, a custom paint match done with i1 Paint will save up to 30 minutes, eliminate mismatched paints, and reduce waste.

Quality Color Matches on Common Samples

- Uses continuous ring illumination for consistent readings.
- Achieves quality color matches with 31-point spectral resolution.
- Reads 8mm portion of sample to accommodate common paint counter requests.

Capture Color Measurement Quickly & Efficiently

- Measures a sample in just one second.
- Facilitates one-hand operation with a portable, lightweight design.
- Triggers measurements from the device and ColorDesigner PLUS paint software.
- Offers simple targeting for samples with a modern instrument housing design.
- Communicates instrument status to operator via multi-color LED indicator.

Minimize Downtime & Optimize Instrument Performance

- Leverages LED illumination for stability and long life.
- Includes a separate calibration assembly that can be secured to the paint counter.
- Prevents damage and reduces contamination to optical components with filter glass.
- Eliminates unnecessary power supply cords with a single USB cable.
- Secures and protects your investment with an optional Kensington security lock.



Achieves quality color matches



Facilitates one-hand operation



Measures a sample in just one second

Make i1 Paint a Complete Solution

ColorDesigner PLUS

X-Rite's ColorDesigner PLUS color matching software expedites and refines the paint selection process to eliminate wasted effort and needless formulation errors. It can connect to a paint dispenser system for fast delivery of paint color formulations, mix the customer's color in the paint product they want, and look up colors across paint lines (optional), turning any paint department into a color design center.

W30 Series

Our W-Series product bundles offer various combinations of color matching hardware and formulation software to meet the needs of retail paint operations of all sizes. The W30 Series is a customizable, cost-effective hardware and software bundle to help paint counter associates match common customer samples.

Service Support & Warranty

X-Rite's color analysis and measurement solutions are engineered and manufactured to the most rigorous quality standards. These standards are backed by comprehensive global service, superior phone and web support, and preventative maintenance options to optimize your long-term investment. We have developed service support and warranty plans that are unique to your organization's specific products and needs.

Learn more by reviewing our service offerings on our website at: www.xrite.com/page/service-warranty. Still unsure of what you need?

Contact us directly at: servicesupport@xrite.com

Specifications

	i1 Paint
Short Term Repeatability - White	0.1 ΔE_{94}^*
Inter-Instrument Agreement	0.4 ΔE_{00}^* average
Measurement Geometry	45°/0°
Light Source	LED
Measurement Spot	8 mm
Spectral Range	400 – 700 nm @ 10 nm
Measurement Time	<1 Second
Status Panel	Multi-color LED indicator
Power	Power through USB 1.1
Connection	USB 1.1
Dimensions	162 mm x 69 mm x 64 mm (6.4" x 2.7" x 2.5")

Full list of specifications available at www.xrite.com/i1Paint