X-rite PANTONE®



eXact Basic Densitometer



Basic Isn't So Basic

For press operators, that need a simple device for color control at the press, the eXact Basic densitometer is the answer. It is an entry-level densitometer designed specifically for CMYK jobs, enabling you to achieve and maintain accurate color throughout the run. Without even pressing a button, you will get the Density and Tone Value measurements you need to make the right ink key adjustments at the press. Replace visual trial and error with fact-based color control that shortens make ready times and helps you achieve a new level of color consistency.

The eXact Basic is also available in a Xp model, that is specifically designed to solve the unique challenges of measuring flexible films.

Benefits

Economical

This entry-level eXact allows users to gather and provide accurate densitometric results in appropriate stages of the workflow.

Efficient

Automatically detect color and patch type, providing quick and clear measurements.

Precise

Integrated white calibration ensures the highest accuracy and consistency with other instruments – all the time.

Upgradeable

As requirements for your organization change, eXact Basic may be upgraded by password to any higher-end spectrophotometer, including the eXact Scan model.

Features and Specifications for eXact Basic

Measurement Functions	Basic
Colors	
CMYK	Χ
Densitometry	
Density	X
All Densities	X
Tone Value	Х
Tone Value Increase	X

Measurement Parameters	Basic
Measurement Conditions	
M0, M1, M2, M3***	Χ
Density Status	
ISO Status A, ISO Status E, ISO Status I, ISO Status T, Status G	Χ
Density White Base	
Absolute, Paper	Χ
Data Interface	
USB	Х
Software	
eXact Manager	Х
DataCatcher	X

X: Included *** M3 option not available for Xp models



Service Support & Warranty

Drawing on our extensive color expertise, X-Rite offers the right level of services on-site, online or on the phone with industry-leading response times, to support and nurture your business. With global full-service contracts, you can ensure your devices are well maintained through X-Rite's Annual Five Point Checkup, uniquely developed to keep devices performing to original specifications. For more information about extended support options, visit www.xrite.com/extended-warranties-services.



