

# Memorandum



Issued Friday, March 01, 2013  
Doc 1.03.13

**SUBJECT: Munsell Neutral Gray – N7/**

N7 Neutral gray should be used within your light booths or light rooms used for doing critical color evaluations. This is in accordance with the recommendation in ASTM - D1729 standard for Visual Appraisal of Colors and Color Differences of Diffusely-Illuminated opaque Materials.

Using the below paint formula can ensure that the surrounding viewing conditions are correct.

The below formula is to be created using Behr paints with Home Depot Colorants.

## Daylight Illuminate

I/L/Flat

PPIFW Ounce Shots: 1/384

	DL	54
1050	EL	43
Quart	FL	59

## Daylight Illuminate

I/L/Flat

PPIFW Ounce Shots: 1/384

	DL	216
1050	EL	174
Gallon	FL	237

## Incandescent lighting

I/L/Flat

PPIFW Ounce Shots: 1/384

	DL	52
1050	EL	45
Quart	FL	60

## Incandescent lighting

I/L/Flat

PPIFW Ounce Shots: 1/384

	DL	204
1050	EL	178
Gallon	FL	236

Formulas generated by: MatchRite®