## **Memorandum**





Issued Friday, March 01, 2013 Doc 1.03.13

**SUBJECT: Munsell Neutral Gray – N7/** 

N7 Neutral gray should used within your light booths or light rooms used for doing critical color evaluations. This is accordance with the recommendation in ASTM - D1729 standard for Visual Appraisal of Colors and Color Differences of Diffusely-Illuminated opaque Materials.

Using the below paint formula can ensure that the surrounding viewing conditions are correct.

The below formula is to be created using Behr paints with Home Depot Colorants.

Dayligh	t Illumi	nate		Daylight	Illumina	te	
I/L/Flat				I/L/Flat			
<b>PPIFW</b>		<b>Ounce Shots:</b>	1/384	PPIFW		<b>Ounce Shots:</b>	1/384
	DL	54			DL	216	
1050	EL	43		1050	EL	174	
Quart	FL	59		Gallon	FL	237	

**Incandescent lighting** 

I/L/Flat

PPIFW		<b>Ounce Shots:</b>	1/384
	DL	52	_
1050	EL	45	
1050 Quart	FL	60	

Incandescent lighting

<b>Ounce Shots:</b>	1/384
204	
178	
236	
	204 178

Formulas generated by: MatchRite®